

WIRING DIAGRAM							
Mini SAS 4i(HOST)			Mini SAS 4i(TARGET)				
plug	PIN	SIGNAL	plug	PIN	SIGNAL		
P1	B17	TX3-	P2	A17	RX3-		
	B16	TX3+		A16	RX3+		
	B14	TX2-		A14	RX2-		
	B13	TX2+		A13	RX2+		
	B6	TX1-		A6	RX1-		
	B5	TX1+		A5	RX1+		
	B3	TX0-		A3	RX0-		
	B2	TX0+		A2	RX0+		
	A17	RX3-		B17	TX3-		
	A16	RX3+		B16	TX3+		
	A14	RX2-		B14	TX2-		
	A13	RX2+		B13	TX2+		
	A6	RX1-		B6	TX1-		
	A5	RX1+		B5	TX1+		
	A3	RX0-		B3	TX0-		
	A2	RX0+		B2	TX0+		
	GND GROUP			GND GROUP			
	A1,A4,A7,A12,A15,A18			A1,A4,A7,A12,A15,A18			
B1,B4,B7,B12,B15,B18		B1,B4,B7,B12,B15,B18					

P/N: SA-8787-H2H-XX

**Desc. : Int. MiniSAS (SFF-8087) -
Int. MiniSAS (SFF-8087), Host to Host Wiring**

Drawings are property of Serial Cables, LLC and for information purposes only. Do Not Edit or Copy

